# Dishwasher quick sheet

A stand-in for the manual that usually lives in a drawer. Two short pages.

*Fictional sample for the Miller home preview on trustmoses.com. Not a real certificate, policy, bill, manual, or contract.*

## Everyday use

- Scrape plates. Load the Miller home machine so the sprayer arm can turn.
- Put one sample pod in the main cup. Close the cup.
- Choose a cycle, then press Start.
- Cancel ends the cycle and drains. The door stays locked for a short sample delay.

## Buttons on this sample model

| Control | What it does in this fiction |
|---|---|
| Cycle | Normal, Light, or Pots. |
| Dry | Heated dry, or air dry if you prefer it off. |
| Start | Begins the selected cycle. |
| Cancel | Stops and drains. |
| Lock | Keeps the controls quiet. Hold for a three-count. |

## Once a month

- Twist out the bottom filter, rinse it, and seat it again.
- Refill the rinse aid when the lamp on this sample model comes on.
- Wipe the door edge so the gasket seals.

## If something seems wrong

| What you see | Sample check |
|---|---|
| Steady tap lamp | The door is not latched. |
| Dishes still gritty | The filter is seated, and the arm was not blocked. |
| Water in the tub | Cancel, let it drain, then run Light once. |
| Will not start | Lock is off, and the breaker for the dishwasher is on. |

Creekside and DW-sample 400 are invented for this preview. No manufacturer's manual, error-code list, or logo is reproduced.

*The dishwasher breaker is space 5 in the laundry-room panel directory. See Breaker-panel-labels.jpg.*

SAMPLE